

Mid 55 - 57 Wire Diagram Legend

- A Battery
- B Starter
- C Generator/Regulator
- D Ignition Switch
- E Wiper Switch
- F Headlight Switch
- G Semaphore Switch
- G1 Turn Signal Switch (U.S. Delivery)
- H1 Horn Button
- H2 Horn Contact Brush
- H3 Horn
- J1 Flasher
- J2 High/Low Beam Switch (on floor)
- J3 Brake switch
- J4 Oil Pressure Switch
- K1 High Beam Indicator
- K2 Generator Light
- K3 Blinker Indicator
- K4 Oil Pressure Indicator
- K5 Speedo Lights
- L1 Left Headlight
- L2 Right Headlight
- M1 Left Park Light
- M2 Right Park Light
- N Distributor
- O Coil P1-P4. Spark Plug Connector
- Q1-Q4 Spark Plug
- R1 Radio
- R2 Antenna
- S1 Fuse Block (behind speedo)
- S2 Fuse Block (drivers side of gas tank)
- T1-T5 Terminal Blocks
- U1-U2 Semaphores
- U3-U4 Front blinkers (U.S. Delivery)
- V1-V2 Interior Light Switch
- W Wiper Motor
- X1-X2 Tail Lights
- Y Interior Light
- Z License Light